




Quiver-XT and Quiver XT-UB User Guide

Quiver XT-UG-v.1.4

02/15/19



This document describes the operation and feature set of the Quiver XT.

Table of Contents

Introduction	5
Quiver Functional Overview	5
Navigation Buttons	6
Inputs and Outputs	7
Batteries 	7
Startup	8
Brightness and Audio control	8
Settings	9
Settings – General	9
Setting Up the FSK Data Carrier Band and FSK frequency	10
.....	11
Background	11
Settings – Measurement	11
Setting operation standards.....	11
Distance scale.....	12
Return band	12
FWD scan list.....	12
Sweep profile	13
Settings - Calibration	13
Quiver XT Operation Modes	14
Passive CPD Radar Mode.....	15
CPD Radar Connection Diagrams	16
Amplifier Connection	18
Tap and Splitter Connection.....	19
End of Line CPD	20
Using CPD Radar in Local View.....	21
Selecting CPD detection filter bandwidth	22
Selecting noise suppression	22
Using the CPD Marker Option	24
Zoom mode in Passive radar	25
Filtering of analog channels - IMPORTANT	26
Active radar mode.....	26
NTC TDR	27
Round trip losses at different passives and understanding RL indications.....	29
RL calculation in case of cascaded connection of passives	30
Auto-calibration for measuring RL	31
Smart RL scale mode	34
Recommended algorithm of using NTC TDR.....	37
TDR Settings – VOP.....	38
Cable type setting.....	38
Recommended TDR signal level	39
TDR run modes.....	39

Connection options of NTC TDR.....	40
Connecting to network components	40
Connecting to an amplifier.....	42
Connecting to a length of cable	43
Spectrum analyzer/Signal level meter modes	44
Return spectrum analyzer mode.....	44
LNA – low noise amplifier	46
Reference level change	47
Scale change.....	48
Markers	49
Using Max Hold	50
Hold feature	51
Saving a Spectrum Analyzer Trace	51
Forward SLM/Spectrum mode.....	52
Examples of actual FWD spectrum signals.....	53
QAM demodulator mode	54
Using the Save Trace Option.....	55
Saving a Trace.....	55
Recalling a Trace.....	56
Clearing Traces	57
Downloading Traces	57
Using CPD Radar in Headend View	58
Calibrator Mode.....	60
Calibrator Connection Diagrams	61
Nodes	61
Alternative Node Calibration	62
Amplifiers	63
Alternative Amplifier Connection	64
Splitters, Taps.....	65
Using Calibrator mode	66
Setting Up the Data Carrier Frequency	67
Selecting the Signal Output Level.....	69
Changing the Output Signal Level	69
Calibrating a Fiber Node.....	69
Turning Calibrator Output Signal ON and OFF	70
Node Scanning Message	71
Calibration Error Message.....	72
Calibrating a Device Other Than the Fiber Node	72
Leakage Detector	75
Max Hold leak level	77
Saving and recalling the leakage trace	78
RTN Simple Sweep Generator.....	78
Sweep Profiles.....	79
Manual sweep profile	79
Fixed sweep profile	80
Creating a fixed sweep profile.	80
Transferring a fixed sweep profile using Q-browser.	81
Quiver Navigator App	81



Loading maps into your Quiver Navigator App.....	82
QR Codes	84
Using the QR Code with the Mobile Quiver Navigator App.....	86
Changing the Quiver-XT Battery Pack 	91
Changing the Q-AMP Battery 	92
Quiver-XT-UB Specifications	93
Q-AMP 5/40 and Q-AMP-5/70 MHz Specifications.....	94



Introduction

Quiver is a hand held, state of the art impairment locator – designed to identify the distance to the fault for both linear and nonlinear distortions. Quiver uniquely contains a CPD passive radar locator, a Network Traffic Compatible TDR, forward and return FFT spectrum analyzer, QAM demodulator, and leakage detector.

Two versions of Quiver XT are available, a standard version which works with the Hunter system, and an unbundled version for stand-alone operation.

The standard version when used with Hunter provides a method of node calibration which allows for quicker and more efficient node scanning and additionally provides a means for the meter to display the impairment as seen as the headend, for confirmation of fix.

Quiver Functional Overview

Quiver performs several functions that vary depending upon the operating mode you choose. Within each operating mode, various screens will appear in the Quiver display. All the navigation buttons are located on the lower portion of the unit.

Navigation Buttons

Power ON/OFF: To turn the unit on, press for 3 second; to turn the unit off, press and hold for 3 seconds and select *Power down* option. Select *Standby* for putting the meter into power saving state with fast launch.

To wake up the unit from the *Standby*, press and hold the power button for 3 seconds. Release button immediately after seeing 'quiver' caption on the screens. If you hold it too long, the unit will shut down.



<ENTER>: Used to confirm changes and to enable some functions.

Exit: press to exit the menu item, note some screens require pushing *Back* soft key instead.

Cursors (arrow keys): Used for scrolling the screen and switching between functions.

Right below the screen window are four function keys that are related to information displayed on the screen.

Forward Signal Input: Connects to the forward test port at the amplifier or fiber node, or to one of the outputs of the QTP-20 Test Probe (used at any device that does not have a forward or return test port).

Forward/Tx/Antenna: Connects to the forward test port at the amplifier or fiber node, or to one of the outputs of the QTP-20 Test Probe (used at any device that does not have a forward or return test port).

Return/Rx: Serves as an input while in either Spectrum Analyzer or CPD Radar mode; serves as an output for the calibration signal when in Calibrator mode.

Battery charger input: Connector dedicated to charging the batteries using either the AC input charger which is supplied with the Quiver, or a car charger that can be purchased separately.

USB 2.0: The USB 2.2 port connects to an IBM compatible PC for stored picture transfer and firmware updating through Q-Browser..

Line passive connections: use QTP-20 test probe that provides power blocking and two bidirectional 20dB test ports. Test probe is not affecting connected devices return loss and not changing frequency response.



QTP-20 test probe.


Batteries

The Quiver contains a specific Li-Ion battery pack. For safety, only use the battery charger supplied with the Quiver. Replacement batteries are available from Arcom. A procedure for battery replacement can be found at the end of this Users Guide.

Do NOT replace the battery pack with any battery pack unless provided by Arcom.


Startup

To turn on the Quiver, push the Power ON/OFF button and **hold for 3 seconds**. Once the unit is on, you will see the following screen, landing on the Operation Modes page.




Brightness and Audio control

Brightness and volume control is accessed by pressing the Brightness / Volume hot key accessed from the main menu page. Use the up/down arrows to adjust volume and left and right arrows to adjust brightness.




Settings

Press the settings hotkey to access various items.



Settings - General

The General setting button contains information on the FSK data carrier and frequency for use with the complete Hunter system (not relevant with unbundled versions of Quiver), as well as Bluetooth name and Pin, and background color changes.



Setting Up the FSK Data Carrier Band and FSK frequency



This section is only applicable for the standard version of the Quiver XT and can be disregarded when using the Unbundled version.

Quiver uses an FSK carrier to communicate with headend equipment. Prior to operating the system, you must set the frequency of the data carrier. The FSK carrier is tuned in a relatively small bandwidth, which means that the Quiver is dedicated to one particular headend or hub at a time. Any time you move to another headend or hub, you must go back and change the Data Carrier.

When starting the Quiver for the first time, the user might have to select the FSK band first. Typically, the Quiver will be set in the factory to the required band. Note that the frequency band is factory preset with the hardware components and changing the band in the settings will not have any result.


If it becomes necessary to verify if the Quiver is set to proper band, that can be done in Settings mode – from the Operation Modes, use the Setting soft key

Note: the selected FSK band must match the internal FSK receiver band.



Background

Allows to change from a white to black background color.



Settings - Measurement



This menu item is dedicated for adjusting all parameters related to the measurements.

Setting operation standards

In order to operate properly in the forwards spectrum analyzer and analog leak detector modes this is necessary to set properly the TV standard that is used by the cable plant. From the main Settings menu select Measure menu item and press <Enter>.

Then select the appropriate standard from the list.

Note: customer dedicated channel plans can be used. The channel plans are firmware dependant.



Distance scale

Select feet vs. meter – this setting is generic across multiple operational modes.

Settings - Measurement	
1. Standard	
2. Distance scale	feet
3. RTN band	meter
4. FWD scan list	

Return band

This configures the return bandwidth of the used, used across multiple modes of operation.

Especially important for proper operation of Zoom feature in CPD radar mode.

Settings - Measurement	
1. Standard	
2. Distance scale	
3. RTN band	5MHz-42MHz
4. FWD scan list	5MHz-65MHz
	5MHz-85MHz

FWD scan list

This feature is used to select channels to display in the SLM, if the user wants to view certain channels instead of all channels.

Channel	Scan
2/57 MHz	+
3/63 MHz	-
4/69 MHz	-
5/79 MHz	-
6/85 MHz	+
95/93 MHz	-
96/99 MHz	-
97/105 MHz	-
98/111 MHz	-
99/117 MHz	-
14/123 MHz	+
15/129 MHz	-
16/135 MHz	-
17/141 MHz	-
18/147 MHz	-
19/153 MHz	-
20/159 MHz	-

Page Up Back Page Down

Sweep profile

Sweep profile allows the operator to review the output frequencies of the stored profiles. Up to 64 frequency points can be viewed for each profile. Use the left and right arrow key to select a sweep profile.

Settings - Measurement	
1. Standard	NTSC
2. Distance scale	meter
3. RTN band	5MHz-65MHz
4. FWD scan list	
5. Sweep profile	#1 (2)
◀ PRESS ▶	
5.0	21.5
6.5	23.0
8.0	24.5
9.5	26.0
11.0	27.5
12.5	29.0
14.0	30.5
15.5	32.0
17.0	33.5
18.5	35.0
20.0	36.5
38.0	39.5
41.0	42.5
44.0	45.5
47.0	48.5
50.0	51.5
53.0	54.5
56.0	57.5
59.0	60.5
62.0	63.5
65.0	66.5
68.0	69.5
71.0	72.5
74.0	75.5
77.0	78.5
80.0	81.5
83.0	84.5
86.0	89.0
89.0	90.5
92.0	93.5
95.0	96.5
98.0	99.5
Back	

Settings - Calibration

Calibration is used to change various parameters at the factory, it is not a setting that a user should ever require access to. It is password protected.


Settings	
1. General	
2. Measurement	
3. Calibration	
<div style="border: 1px solid black; padding: 10px; margin: 10px auto; width: 100px;"> Password <input type="text"/> </div>	
Software release XT4.5	
Operation	Trace
Settings	⚙️ 🔊

Quiver XT has 8 main operating modes.

CPD radar mode contains an active and passive radar and is used to precisely range distance to CPD or nonlinear distortion.

NTC TDR mode contains a network traffic compatible TDR which precisely ranges distance to linear distortions by providing visibility to the return loss across the entire cable span up until the next amplifier.

Spectrum analyzer/Signal Level Meter (SLM) mode contains forward and return FFT analyzers as well as a convenient signal level meter function.




QAM demodulator allows to view constellation.

Leakage detector mode contains an analog detector that can detect any analog carrier on the network.

Calibrator mode is used to calibrated nodes when used as part of a complete Hunter system.

The RTN Sweep (SSG – Simple Sweep Generator) is used to insert the sweep signals into the network for balancing. The sweep can be viewed by the Quiver itself, or connect your smart phone to the Arcom Simple Sweep web page.

In Passive CPD Radar Mode, Quiver performs one of its primary function – calculating the time distance to CPD sources located downstream of the network connection point. Quiver has the ability to see multiple CPD sources and display each one as a peak on its LCD screen. The user can view all the peaks in the CPD response, which are indicated by markers on the LCD screen.




When selecting “Passive CPD radar” from the main menu you are presented with three options.

Standard fixed BW 8–16 MHz –This is the selection most likely used. Although you can adjust upper and lower frequency limits, this selection captures CPD at 12 MHz \pm 4 MHz.

Narrow adjustable BW 4 MHz –This option provides a fixed 4 MHz BW, but the center frequency can be adjusted from 8 to 90 MHz.


Wide BW 5–100 MHz –This selection detects CPD using in the complete 5–100 MHz Return Band.



While using CPD radar with a Quiver XT you have the option to operate in either local or headend mode. In local mode the distance to the CPD source is displayed as described above. In headend view mode, the Quiver shows the CPD as the distance seen from the fiber node, as measured by the Hunter system at the headend. The Headend view mode feature is not available on the unbundled Quiver XT-UB.


In order to use CPD Radar Mode, you must establish proper connection to the network devices. The diagrams illustrate the proper CPD/leg Isolation setups to use for the various devices in the network.

CPD Location/Leg Isolation At Single Output Amps/Fiber Nodes with Close Splitters/Taps




Node Connection – Single Output Amp/Fiber Node

CPD Location/Leg Isolation at Fiber Node




Node Connection - Isolation at Fiber Node

CPD Location/Leg Isolation at Amplifiers



Node Connection – Isolation at Amplifier


CPD Location/Leg Isolation at Tap and Splitters



Tap and Splitter Connection – Isolation at Tap/Splitter


CPD in the drop line is normally not possible due to low forward signal levels. It might happen if the drop is feeding and MDU with an amp inside or there is an amp in the subscriber home. When you get to the last tap at the end of line and suspect that the CPD is coming from a house, you will have to use the Quiver radar or Headend View if full Hunter is installed. Connect the Quiver Forward Port to the tap and keep disconnecting the houses (tap ports 1 – 8) one by one while watching the Quiver screen. If you disconnect a house (tap port) and at the same moment the CPD signal disappears, that house is the CPD source.

End of the line situations



End of Line CPD

When you activate CPD Radar Mode from the Operation Modes (by hitting key 1 or highlighting with the cursor buttons and pressing <ENTER>), the default is Local view. The following screen will appear:





The Quiver is constantly scanning for CPD sources, and you will see slight changes on the screen as the scanning occurs. To stop the Quiver from scanning, you can press the Stop soft key which will be renamed into Run key. Press the Run soft key when you need it to resume scanning.

The Quiver display defaults to the medium Delay Range of 0–25 μs. If you want to change the delay range, open menu item Delay scale by hitting key 1 and pressing <Enter>. The dialog box will open where the following settings can be selected with ^ and v cursor keys. Range can be selected as 0–5 μs, 0–25 μs, or a maximum of 0–

50 μs.


Delay Range 0 – 50 μs and 0–5 μs is shown to the right.



It is important to note that the time delay span does not change the instrument resolution of the CPD peak which remains constant. The benefit is that in smaller time delay window the scan is completed much faster than in the full time delay span saving time in the field.

Selecting CPD detection filter bandwidth

The return signal input filter bandwidth can be changed in order to reduce the influence of CW-like carriers in the return path on the radar signal processing circuitry. If they are present within the 8–16 MHz and elevate the noise floor on the radar screen the bandwidth of the radar input filter spectrum can be shifted up to reduce their impact. That allows for selection of a quieter frequency band where processed signals will create more clearly visible CPD peaks. For changing the filter bandwidth set the BPF freq. min. and BPF freq. max parameters by selecting menu items 2 or 3 accordingly and pressing <Enter>. The drop-down list with frequencies will open.





From the frequency list select desired value and press <Enter> to confirm. Then adjust the other end of the bandpass filter in the same fashion if necessary. It is important to remember that the more narrowly the filter is set the lower the detected CPD peak will be shown and its peak will be slightly wider.

Selecting noise suppression

For further improvement of noise cancellation, it is possible to select High Noise Suppression. In High Noise Suppression mode, the radar processes a larger number of signal samples and creates a CPD response based on more information collected during a longer time period. The user will see on the screen the noise floor decreasing after each scan while the CPD peak will remain at the same level.

To select High Noise Suppression mode highlight menu item Noise Suppression with the cursor buttons or hit 4 on keypad and press <Enter>.


Then in the appearing dialog box select High using the ^ or v cursor key and press <Enter> and the screen will look like shown on a picture below:



Noise compression settings screen


Please note that now a single scan through the full range of time delay for CPD signals may take long – up to 180 seconds. The expanding horizontal blue bar at the top of the screen is indicating the scan progress. If the CPD peak is well visible and identified, there is no reason to wait for the entire scan.

To scan again once the first scan is over press Run soft key.



Using the CPD Marker Option

Quiver automatically sets a marker at the maximum level in the CPD signal response. To move marker to a next or previous peak, use the ∇ to highlight menu item Marker or hit 5 on keypad and press $\langle \text{Enter} \rangle$ to open the dialog box then use the \wedge and \vee cursor keys select ' $\langle \rangle$ ' item and press $\langle \text{Enter} \rangle$ to confirm:




Then use \langle and \rangle cursor keys to move the marker to the right or to the left of the scale.

The actual time delay value of the marker position displays in the upper right corner of the screen. Once you have the time delay value of the marker position (maximum CPD), you will use it to search the system for candidate devices in the Quiver Navigator software or in the Navigator contained within Quiver if option installed. The distance to the CPD source is displayed right below the delay value.

Note: This distance is calculated using averaged VOP of the cable and does not reflect the data on the system map. It provides an approximate distance to the source in meters or feet.



In this mode the CPD correlator works with the full return bandwidth, 5–42/65/85 to provide better time/distance resolution as well as better time delay accuracy. The return bandwidth of the cross correlator is selected at Settings – Measurement.

Time delay span in Zoom mode covers $\pm 2\mu\text{s}$ from the peak under marker. Peak under marker is shift to the screen center after pressing Zoom button. Before using Zoom, make sure that is the Settings_Measurement menu is properly selected your return path band. If settings are correct press the Zoom button to activate from the Passive radar screen.



Actual zoom response example is shown below:

- In Zoom mode the peak under marker is placed in the center of screen – with display x-axis showing $\pm 2\mu\text{s}$ from marker.
- Note – CPD peak time delay indication in Zoom mode is more accurate due to use of more return path bandwidth in signal processing.





Filtering of analog channels – IMPORTANT

For the Passive CPD radar to operate properly, only digital channels can be presented to the correlator processor. Analog channels need to be filtered and removed. Quiver XT contains an internal high pass filter that removes all analog channels above a specified frequency. If Quiver XT is used on a network with analog channels carried above the cutoff of the internal filter, an external high pass filter must be used. This external filter should be placed on the FWD in port when using the Passive CPD radar mode. The filter should be removed when using all other modes.

Active radar mode

The active CPD radar mode is designed to allow for testing the home network or alternatively for certification testing of new construction in plant that is no yet active. **THIS MODE WILL BE DISTRUPTIVE TO NETWORK TRAFFIC AND SHOULD NEVER BE USED ON LIVE PLANT – A WARNING MESSAGE IS INDICATED PRIOR TO THIS MODE BEING ENTERED.**

In active CPD radar mode, a radar chirp signal is generated in the 150–250 MHz band with level 30..50dBmV. The reflected CPD signal is formed at a bandwidth between 2–100 MHz.

When connecting to the home network when the use of test points or the QTP–20 probe is not possible, a high band/low band diplexer similar to that as shown below should be utilized. **Additionally, a 150MHz High pass filter should be utilized on the forward transmit port to improve the isolation of the diplex filter.**

HIGHBAND/LOWBAND SEPARATOR/JOINER

Combines or separates high and low band VHF signals. Provides low insertion loss prior to channel processing and allows the balancing of bands prior to amplification.



MODEL HLSJ

PORT	Insertion Loss		Rejection	
	FREQUENCY (MHz)	TYP	FREQUENCY	TYP
LOW	DC - 130	.5 dB	170 - 600	25 dB
HIGH	170 - 600	.7 dB	DC - 130	25 dB




Band separator and high pass filter connections for the Active CPD radar mode

NTC TDR

The NTC TDR identifies the precise distance to micro-reflection problems and impedance mismatches in the plant. It is used as a field tool to locate problems identified from PNM initiatives. The NTC TDR is completely different from any other existing TDR. The NTC TDR calculation of the time distance and corresponding physical distance to the impedance mismatch is based on an autocorrelation process which utilizes very low level non-intrusive spread spectrum signals transmitted at return path frequencies in the forward. It is effective from the connection point to the next amplifier.

A general illustration of how the device operates and is connected to the network is provided in the figure below. Here a spread spectrum signal is input through an amplifier return in test port, the signal travels through the network to the next amplifier (where due to the presence of the diplex filter the probing signal can go no further), and signals are reflected back at all points not having a perfect 75 ohm match and the reflected signal is detected and measured at a second return out test port. (For simplification only one reflected signal is shown.)



WHEN USING THE NTC TDR CONNECTED TO AN AMPLIFIER, PLEASE BE VERY CAREFUL IN SELECTING THE PROPER TEST PORT AS THEY ARE DIFFERENT THAN WHAT IS TYPICALLY USED – THE INPUT NEEDS TO BE RETURN INPUT IN THE FORWARD, AND OUTPUT NEEDS TO BE RETURN OUT IN THE RETURN!

The NTC TDR output display is unique in that it provides a presentation of easily understandable return loss across the measured span of plant between two actives. This output format is significantly improved over that provided by status quo TDRs which just provide difficult to interpret impedance bumps indicating shorts or opens.

This paragraph explains method of measuring RL in NTC TDR.

The main concept of measuring RL is illustrated below in block diagram Fig. 1. The TDR generates and injects a probe signal with level P_{tx} into coaxial cable in the direction towards the device under test (DUT). The reflected signal from the DUT at the injection point of Tx signal, has level P_{rx} . The Return loss (RL) of the DUT is calculated by using formula:

$$RL (dB) = P_{tx} - P_{rx} - L_{coax},$$

where L_{coax} (dB) are the roundtrip losses of the probe signal in coaxial cable.




Fig. 1

The roundtrip losses at coaxial cable are calculated in Quiver dependent upon the type and length of cable. The length of cable in turn is also calculated from, and dependent upon the specified velocity of propagation (VOP) and the time delay. As a result, the TDR response in the form of its "RL-time delay" screen has been modified to include a time delay linear tilt, which compensates for the roundtrip losses within the coaxial cable. Fig. 2 shows the parameters used for calculation of roundtrip losses at cable and tilt of TDR response.

Tilt of TDR response for compensation round trip losses of the coaxial cable




Fig.2

RL calculation in case of cascaded connection of passives.

Block diagram shown on Fig.1 is for the most simplistic scenario of measuring RL. But a more common scenario for coaxial plant in the HFC network is where some number of passives are connected in cascade between the TDR connection point and the DUT. Actually, in this case each passive is a DUT because probe signal will be reflected from each of cascaded passives and the task of the technician is to detect device with worst RL. Below on Fig.3 is shown example of two cascaded passive devices between TDR and DUT and corresponding response of TDR.




Fig. 3

In case of N cascaded passives (taps, splitters, directional couplers etc.), in order to correctly measure RL, the roundtrip losses for each passive device between the TDR and DUT (the peak of interest shown on the TDR response) should be taken into consideration:

$$RL \text{ (dB)} = P_{tx} - P_{rx} - L_{coax} - \sum (L_i), i=1,2,\dots,N$$

where L_i is round trip losses at passive device "i".

Obviously for correct calculation of RL in the case of cascaded passives, information is required about each type of passive. For example, roundtrip losses for a tap is approximately

2 dB, for a splitter approximately 7 dB, and for a directional coupler DC-6 (dB) it will approximately 12 dB at the tap port.

It's definitely impossible without a network map, looking solely at analysis of the TDR response - to precisely define the roundtrip losses for each device (for each peak of TDR response). That is why some creativity and deep analysis is required from the technician for estimation of actual RL at each of the reflected peaks. Electronic map analysis is a perfect solution to this problem. Quiver Navigator app available for iOS and Android devices can be used in conjunction with prepared electronic plant schematics.

Auto-calibration for measuring RL

According to the formulas presented above, for calculation of RL it is required to know the transmit level P_{tx} of the probe signal, and the level of the received signal P_{rx} at point of the TDR connection. But the TX signal level at TDR can be changed depending on temperature and other factors. Also, when the NTC TDR is connected to IN and OUT test ports of amp (see below Fig. 4) the gain of RTN amp is not known with certainty, so, this creates difficulties in measuring actual level of reflected signal at point of injection TX probe signal.




Fig. 4

Both factors mentioned above (uncertainty of P_{tx} and P_{rx}) create difficulties in the calculation of exact RL. To overcome this issue at the NTC TDR we use an auto-calibration procedure. The idea of this procedure is based on fact that in case of connection with probe QTP-20 the losses of probe from connection ports to central pin (20 dB) are very stable and isolation between connection ports is also very stable (-40 dB) and well known (measured at lab conditions). Also, what is very important, the losses of the QTP-20 and the port-to-port isolation do not change with mismatches at coaxial line. So, this allows us to use the leak signal level from port-to-port (peak at zero time delay) as a reference calibration level corresponding to Zero RL. This method is illustrated at Fig. 5 and it allows for a very accurate measurement of RL in case of using the QTP-20.




Fig. 5

In the case of connection to the IN and OUT test ports of an amplifier, the maximum of first peak is placed to a point where $RL=20$ dB. The assumption behind this is that that RTN input taps (-20 dB tap) are assumed to have isolation of -40 dB, so, leak signal will be on 20 dB below reflected signal in case when $RL=0$ dB (see Fig.6).

It should be noted that in cases of connection to an amp, the measurement of RL is not as accurate as in the case of connection by QTP-20 because assumption about isolation at input tap -40 dB may not be correct for some amps. Also in this case isolation of input tap will depend on the load (mismatches) at the input of amp and results will vary. The isolation at input tap may vary from expected value -40 dB to -30 dB in worst case. It means mistakes in precisely measuring RL can be up to 10 dB.

Thus, in case of connection to amp, it makes sense to just select the peak with the worst RL and if this peak will be on 5...10 dB higher than adjacent peaks, then it will mean that anomalies of RL (mismatch) are at device corresponding to that peak. For more accurate measuring RL at above device it makes sense to connect by QTP-20 to next passive after amp to measure RL more accurately.




Fig.6

From the other side, in many cases the typical coaxial network between adjacent amps consists of cascaded taps only. Such typical scenarios are shown on below Fig.7.






Fig.7



In the case of cascaded taps, it will be a close enough approximation to assume that each tap has round trip losses of 2 dB. This assumption allows to adjust the TDR response for a more correct estimation of RL for each peak (device). The idea of correction of the TDR response is shown in Fig. 5. As shown, the response of the TDR is shifted up by 2 dB after each peak, and the RL for the next peak will be corrected by 2 dB (round trip losses at previous tap will be taken into consideration).

This mode is named as “Smart RL scale” and it’s already implemented at last releases of Quiver XT and Quiver S software (see Fig.8). It is an automated way in which we can manage the tap device insertion loss to provide a more accurate indication of return loss.

Of course, the user needs to be aware that for reasons previously described, if there are splitters within tested network span while the Smart scale is being used, that the actual RL will be different from that which is indicated.



Smart scale is OFF – and as such the TDR is configured to ONLY compensate for the roundtrip cable losses – the red line is intended to illustrate this.




Smart scale is ON – and as such the TDR is configured to compensate for the roundtrip cable losses AND to compensate for 2 dB thru loss for each tap – the red line (which does not appear on the screen) – is intended to illustrate this. The two screens on the left show how the marker showing the RL of the peak has changed in value when Smart scale is turned on. (the right screen shots are not intended to illustrate the change in RL value).

Fig. 8

Again, it should be noted that Smart RL scale option is not guaranteed from some mistakes of reading RL because if splitter is installed instead of tap, then all peaks after the splitter will be showing better than real RL and should be additionally re-calculated with correction coefficient: (7 dB (splitter) - 2dB (Tap)) = 5 dB.

Thus, even with activated Smart RL scale mode the technician has to look on a map and make some re-calculation in his mind for the correct estimation of RL. In cases when a splitter or directional coupler is installed after current point of connection, it makes sense to do next RL measurement at the split point looking at different directions.

It makes much more sense to do this as opposed to looking at the cable span backwards from the other tap. The NTC TDR is different from legacy TDR's and in practice it should be used differently. This step of looking backwards from the amp provides minimal added value. However, it should be used if the amplifier has a resistive bidirectional test point at the input and is offering only this type of connection.



Indication difference example.

Step 1 - go to amp located before zone of expected problems (micro-reflections etc). If our required test points are not available, then as an alternative connect to first passive device after the amp

Step 2 - connect to amp or passive and select peak at TDR response with the worst RL.

Step 3 - if selected peak is located after some split point, then go to the split point and connect TDR by using QTP-20 probe to splitter (or directional coupler). Note that if you are connected to the passive after the amp the actual nearest to zero indicated problem can be the amp and not the next device. This is due to the fact that the TDR is seeing in 'both directions' as they were all in one direction.

Step 4 - measure RL and time delay/distance and go to device with mismatches.

Remarks

#1: if you are seeing close to good RL at a peak that is shown after a couple peaks and you know that before these peaks are DC or splitters then measure again from that DC or splitter because the roundtrip loss of the DC and splitter will 'virtually improve' the indicated RL. Splitter will cause all the peaks coming from after this device being shown by around 6dB better than they actually are. The meter doesn't recognize what device types are in front of it.

#2: testing right on the device is tricky as the TDR needs some distance between itself and the device under test (DUT). If you try to test device at the site then use longer test cable. 10 to 15 meters additional distance will allow for proper identification of the zero peak and the actual DUT peak. Otherwise user might see just a wider zero peak.

#3: make sure you set up proper cable type and proper VOP parameter of the cable

#4: turn on Smart Scale


TDR Settings – VOP

The velocity of propagation number should correspond to the type of cable being testing according to manufacturers' specification. A typical value is 87 % for trunk and distribution cables. Drop cables will typically have 85%. Quiver uses calculated time distance from the time the pulse is sent to the time it is received – so this velocity of propagation number is important in order to accurately calculate distance to the fault. If the velocity of propagation number is changed, the indicated distance to the impairment will correspondingly change. Note that time delay indication is not influenced by VOP. After selecting the VOP menu item, use the keyboard and enter the two digits corresponding to the VOP then press enter – the device will add the decimal and percentage symbols.

velocity, %	
1. VOP	—
2. Cable	
3. Mode	


Cable type setting

For the NTC TDR, the type of cable being used in the network needs to be selected from the drop-down list using the up and down arrow. The type of cable indicator contains information related to the insertion loss characteristics of the cable and is used in our normalization process such that return loss remains relatively flat and accurate across the band. This information is used to make the return loss indication more accurate and does not affect the distance to the fault measurement.



Recommended TDR signal level

The default transmit level for the TDR is 0 dBmV. Under typical conditions this will result in the spread spectrum signal being -40dBc relative to the return QAM channels – significantly lower than the -25dBc level defined in the DOCSIS specification as what is required not to affect the return QAM CNR/SNR. As such the 0 dBmV level should be used in most connection scenarios. Caveats to this would be when the connection point is an amplifier with -30dB test points instead of the more common -20dB test point – where stronger transmit signal levels would be required. Another case where the higher signal level might be needed would be in sections of plant with larger than typical numbers of passives (older architectures). The lower level -5 or -10 dBmV settings would be recommended for end of line type situations or at the drop when plant signal levels are minimal.




TDR run modes


Two TDR run modes are available:

Continuous – where it will continue to actively send out pulses and measure return loss response.

Single – where only one pulse will be sent out.




Due to differences in required signal level there are three connection options available. When entering NTC TDR mode the user must first select the connection method of Probe or Amplifier or Splitter which can be used for connecting to a cable length or a single device and press Enter. Then check settings to confirm VOP and Cable type. Note that selecting cable type is not causing VOP change. This is because different cable vendors make cables marked as same type, but they can have different VOP.




Connecting to network components

As an alternative connection methodology, the NTC TDR can be connected directly to a line passive where the forward and return connection is made by using the QTP-20, a 20dB 2 port test probe connected directly to the center conductor via the seizure screw access port as shown below. For this type of connection please select Probe QTP-20 from the connection menu.



Quiver S shown instead of Quiver XT




The spread spectrum probing signal transmit signal can be set from -10 .. $+10$ dBmV, the recommended and default level is 0 dBmV. This signal level range is considered safe and will not be disruptive to any traffic. The probing signal levels are below the return noise floor and they are not visible to the spectrum analyzer.

From a simplicity perspective, the most desirable point to connect the TDR to the network is at the first line passive in a span of cable (from amplifier to the next amplifier). Connection is made by using a QTP 20 resistive test probe that attaches directly to the center connector seizure screw via the seizure screw access port on the line passive. The Tx and Rx cables can be connected to either of the QTP 20 output ports.

When connecting with a probe, depending upon signal levels it might be rarely necessary to use an external return amplifier to boost signal levels. The Arcom Digital Q-AMP is designed for this purpose. Since we need to amplify the very low level Received (Rx) signal, the Q-AMP must be placed on the Rx port, and the user needs to pay attention that the input to the Q-AMP is on the probe side and the output is on the meter side.

When connecting to an amplifier, great care and attention needs to be given to ensure the proper test ports are utilized and connected to the proper transmit and receive ports. The required configuration is illustrated below – where the 5–42MHz transmitted signal is inserted in the forward direction via a return input test port such that it can pass through the diplex filter, and the reflected signal is received by a return output test port.

For this connection use **Amp IN/OUT test ports** option in the connection menu.




1. **Forward test points can't be used!** – They will be either in the wrong direction or they will insert into the high side of the diplex filter where they will be attenuated and will go no further.
2. **Ensure the directional coupler is in the proper direction** – Tx. signal is inserted in the forward, Rx. signal is received in the return.
3. **Connecting to a line passive using a test probe is an alternative and a more simple connection process.**

If the amplifier is equipped with limited number of test ports and offers a resistive bidirectional test port then use a two way splitter with the outputs connected to the transmit and receive ports of the TDR without additional attenuator pad and select in connection menu **Splitter to -20dB port**.

Connecting to a length of cable

When using the NTC TDR on a single length of cable, in order to display proper results, it is recommended to use a two-way splitter with the outputs connected to the transmit and receive ports of the TDR, and with a 20dB pad installed between the splitter input and the length of cable as shown in the diagram below.



This type of connection can be used for testing cable, disconnected plant section. It also is used when testing a single device. Note that in case of testing a single device it's necessary to connect it with additional 10–15m of cable length to avoid near zero time delay dead zone effect where the zero peak can be covering the peak created by the device under test (DUT). When testing single device and cable and large reflections it might often happen that the multiple reflections are seen on the screen. This is easy to identify that because there will be same time delay spaced peaks with evenly dropping levels.


The Holland GHS-2PRO splitter was selected for this application because of its outstanding >42 dB return path port to port isolation performance. Similar replacement splitters should be used to ensure proper TDR measurements.

Spectrum analyzer/Signal level meter modes



Two spectrum analyzer modes are available. Forward signal analyzer offers also SLM capability and narrowband spectrum analyzer for selected channel spectrum watching.

Return spectrum analyzer mode

Bandwidth of the return spectrum analyzer is 100 MHz. Enter RTN mode and connect return input to the indicated port.



To set up Start frequency, highlight the settings menu item <Min frequency> by using the cursor keys or hit 1 on the numerical keypad and press <Enter>. Then in the appearing dialog box type in required frequency using the numerical keypad and press OK soft key.





Selecting Min Frequency

Should you make an error typing in the frequency, use Clear all soft key to clear the field and type the frequency again.

To set up Stop frequency highlight the settings menu item <Max frequency> by using the cursor keys or hit 2 on the numerical keypad and press <Enter>. Then in the appearing dialog box type in required frequency using the numerical keypad and press OK soft key.

Should you make an error typing in the frequency, use Clear all soft key to clear the field and type the frequency again.




Selecting Max Frequency

LNA – low noise amplifier


The analyzer has 20dB LNA that can be turned on when watching very low signals. Note: this is very easy to overload the input when the LNA is turned ON. Use it only when you are sure the unit is not overloaded by additional gain. To turn the LNA on press key 3 on the numerical keypad or highlight this menu item with the vertical cursor keys then press <Enter> to open the On/Off submenu:

In the submenu, highlight required On or Off state with the vertical cursor keys and confirm selection with <Enter> button. The scale is automatically corrected to actual input gain.

Always make sure the LNA is Off when watching normal level signals.




The reference level can be changed to view signal details especially when the scale of 5dB/div is used. The screen can show only five menu items at a time, so to access this setting it is necessary to scroll down to menu item 6 by using the down scroll cursor key or directly pushing number 6 on the numerical keypad:



Then press <Enter> to open the reference level submenu. In the submenu highlight required value with the vertical cursor keys then press <Enter> to confirm selection.

Scale change

The signal level scale is set in default to 10dB/div. It can be changed to 5dB/div. The screen can show only five menu items at a time, So, to access this setting it is necessary to scroll down to menu item number seven or push 6 on the digital keypad. Then press <Enter> to open the Scale submenu:



The submenu offers two scale/ div settings: 10dB and 5dB. Highlight the desired one and press <Enter> to accept the change. After changing the scale to 5dB/div. it might be necessary to adjust the reference level as well.


Markers

The analyzer has two markers available. Additionally, the instrument shows the difference in frequency and the level indicated by the two markers. That data is available on the upper part of the display as Delta value.

To activate the marker, use the cursor keys or hit key 4 or 5 to highlight required <Marker> field and press <ENTER>. Then select desired marker mode using the '^' and 'v' cursor keys.

Four marker modes are available.


- The default mode is Max which means the marker will be put atop of the max signal level frequency.
- The second marker mode is offering free selection of the frequency where the marker is positioned. When the second mode is selected the maker can be navigated with the '<' and '>' cursor buttons.
- The third mode allows for the direct frequency input and selecting with the numerical keypad where exactly the marker should be put.
- The fourth mode is Marker OFF where the particular marker is deleted from the screen.



Using Max Hold

The Quiver has two Max Hold functions available. The basic Max Hold operates as a typical spectrum analyzer feature. Additionally the current Max Hold result can be stored on the screen temporarily and with the Hold function another signal source Max Hold can be compared with the previously stored on the same screen offering easy signal comparison. This is very helpful in working with noise and impulse noise when fine details of the spectrum on the two sides of a splitter or tap need to be compared

To activate Max Hold hit <Hold Max> soft key. To deactivate Max Hold press <Max Hold Off> soft key.




Hold feature

When the Max Hold is turned on, additional max hold function becomes available. It allows the current max hold pink line to be saved on the screen and the next signal Max Hold to be superimposed on the screen. Then a couple seconds later user can compare it on the same screen with the Max Hold of the signal at another leg of the plant. To turn it on, press the Hold soft key. Once activated, the first Max Hold line turns green and the next signals' Max hold line will be pink. This mode is very helpful for finding direction when ingress troubleshooting.


Exit the Hold mode by pressing the Off soft key.

To the right is a real example of Max Hold and Hold feature.




Saving a Spectrum Analyzer Trace

To save a Spectrum trace, use the <Save> soft key. Next, press the <Yes> soft key to confirm selection and the screenshot will be saved into the memory. The traces are available for downloading using the USB port and the Q-Browser software.









Forward SLM/Spectrum mode

In this mode the unit can function and toggle between a Forward spectrum analyzer and signal level meter. First ensure the FWD signal is connected to the correct port. In the SLM mode the unit automatically detects the type of signal for each selected channel: Analog, QAM, OFDM, or noise. Then any channel can be selected at List to switch to the very fast FFT spectrum analyzer mode with RezBW=10kHz and Span 8MHz. Option after selecting forward is either Full band, where the entire frequency spectrum is presented – or Scan list – which is a subset of this on channels that the user has selected through the Settings – Measurements – FWD scan list option.






Detailed channel spectrum



QAM demodulator mode

QAM demodulator mode is very simple. It is required to capture signal samples for 30 seconds.




Using the Save Trace Option

The Trace option allows you to save screens into the Quiver's memory. The traces then can be viewed on the Quiver screen or downloaded into the PC with help of Q-Browser software. The Q-Browser also allows for uploading maps into the Navigator in the meter.

Saving a Trace

To save a Trace, simply press the Save soft key then respond Yes, and press <ENTER> to store into Quiver's memory. When the save is complete, you will hear an audible signal when sound enabled.



Recalling a Trace

Saved Traces can be recalled and reviewed. To recall saved Traces from memory, press Trace soft key from the Operation modes screen.




Accessing saved traces



Then highlight required screenshot type on the list, for CPD radar select 1.CPD radar or hit key 1 on the keypad and press <Enter> to open the records list.

On the open records list select required record with the cursor keys ^ and v then press <Enter> to open the record.



Note: While viewing a recalled trace, the Marker option is NOT active.


Clearing Traces

Once you have resolved a CPD issue, you can clear the saved traces from memory. To delete the traces use Q-Browser and the mini USB port on the instrument. Refer to the Q-Browser manual for the feature description.

Downloading Traces

The traces can be downloaded with the Q-Browser and the mini USB port on the instrument. Refer to the Q-Browser manual for the feature description.

To switch CPD Radar from Local to Headend the instrument must be in the CPD radar mode first. Press the Headend soft key to activate feature that makes the meter display on the screen the actual CPD view from the headend radar. The Local soft key will navigate back to the local radar mode.



CPD Radar Mode, entering Headend View

Note #1: you can see in the headend view the CPD only for the node which node ID was set in the Calibrator.


Note #2: the headend view is able to show the CPD properly only for the previously calibrated nodes.

Tip: to speed up the refresh rate of the headend view make sure the nodes of you interest are selected in the Scan Scheduler with the Xcor Client. Another option is to use the live CPD access in the webview mode on the smartphone.

When the Quiver is in Headend view, you will see the Node IDs cycling sequentially on the screen as they are scanned by the Headend Radar. The red vertical bar on the screen during scanning corresponds to the CPD response from the node you selected in <Node ID> setting field in Calibrator

mode (see setting Node Number). When Headend Radar receives data for that selected node the Quiver generates an audible signal and the text “Scanning node # xxx” under the Delay axis graph changes from blue to red. Then the vertical bar changes color to blue when cycling through other nodes. The CPD’s time delay signal is shown above the vertical bar on the graph. The value shown is the time distance as calculated from the fiber node – the distance between the headend and the node is automatically subtracted.

Headend view is useful for quickly checking if a repair was successful, or to check end of line conditions as mentioned above in the CPD Connections section.






Calibrator Mode

Calibrator mode is used to find the exact time distance to a device from the headend. Quiver does this by simulating a small source of CPD that the headend recognizes as originating from Quiver. At the headend, the calibration information is updated into the Hunter server database, which contains information about every device in the network. This database is exported from Hunter to the Quiver Navigator software along with the electronic system map.

Although all devices in the network can be calibrated, **we recommend only calibrating the fiber nodes**. Node calibration is necessary for proper operation in the headend view mode and is required in order to optimize scanning time for each node. When nodes are calibrated, the scanning rate increases. This is not so important for low node count hubs, but for larger systems it is of benefit.


Caution – You cannot put power through a device

Nodes




Node Calibration

With this connection multiple calibrator signals are present due to poor return loss of the components and signal reflections. To eliminate this problem, we recommend using internal test ports when calibrating the fiber node.




Alternate Node Calibration

Amplifiers




Amplifier Calibration

With this connection multiple calibrator signals are present due to poor return loss of the components between the amplifiers. If this occurs, remember to use the strongest peak as a calibrator signal when choosing signals for validating calibration data in the database.




Alternate Amplifier Calibration



Tap/Splitter Calibration


To activate the Calibrator Mode, go to the Operation Modes and use the cursor buttons to < to highlight <Calibrator> or hit 4 on the keypad then press <ENTER>.

The following appears on the screen:



Entering the Calibrator Mode

Setting Up the Data Carrier Frequency



Calibrator mode

Forward path input Return path input

Node #23


Set up all parameters and then press START

1. Output level	25 dBmV
2. Data carrier	78.00 MHz
3. Node ID	23
4. Start	

In most situations this operation is done once and will have to be repeated once the FSK carrier frequency has changed or the Quiver is moved to a different hub that is using same FSK band.

The Frequency of the FSK receiver is agile in small range and can be changed from the Calibrator menu.

To access it open Calibrator item from the Operation Modes screen:



1. Output level	
2. Data carrier	78.00_
3. Node ID	
4. Start	


OK Clear all Cancel

Highlight Data carrier menu item and press <Enter> to open the frequency adjustment dialog box:

In the open window press the Clear all soft button to remove existing setting. Then type the desired frequency digit by digit using the numerical keypad. Should you make an error, you will have to clear all the digits with the Clear all soft button




and retype the frequency. Once the frequency is input is correct, press OK soft button to store new data.



Then to change the node ID use Clear all first then type in the node ID using the numerical keypad and confirm selection by pressing <Enter>.

Selecting the Signal Output Level

If you have just set the Node ID, use the \wedge to highlight Output Level menu item and press <Enter>. The Output level adjustment dialog box will open:



Changing the Output Signal Level

In the open window press the Clear all soft button to remove existing setting. Then type the desired output level value digit by digit using the numerical keypad. Should you make an error, you will have to clear all the digits with the Clear all soft button and retype value again. Once the data input is correct, press OK soft button to store new Output level. Start by setting the output signal at a low level for example 5 dBmV.

Calibrating a Fiber Node

Before you can calibrate a node, you must make sure that you have set up the Data Carrier, Set the Node ID, and Set the Output Signal Level. See the Start-Up section of this manual before continuing the node calibration process.



Note: You will need to change Node ID and Output Level at each calibration site.

Turning Calibrator Output Signal ON and OFF


Once you have set the parameters required for node calibration (Data Carrier, Node Number, and Output Signal Level) you will switch the output signal On so that the Quiver can send its simulated CPD signal to the headend radar. To switch the output signal to On, use the ∇ to highlight menu item Start or hit 4 on the numerical keypad then press <ENTER>.

Use the left most soft key to answer Yes and press <ENTER>. Always make sure you are at the fiber node. At this point, the Quiver uses all the parameters you have <Enter>ed (Data Carrier, Node Number, Output Signal Level) in the Calibration process. Using the Data Carrier, the Quiver sends a signal to the headend radar and waits for a response.

During scanning, while waiting for confirmation from the headend, you will see the screen below:




However, if the Data Carrier frequency was set incorrectly, or if the forward signal connection is bad, or if the forward signal level is too low (less than -5dBmV) the following error message appears on the screen:




If you receive this error message, first check the connection and then check the Data Carrier, then switch the output signal on to try calibration again. Repeat this process until you the forward signal ok message.

When the Headend Radar successfully receives the calibration signal the Quiver receives the confirmation signal and displays the following successful node calibration message:

In this case no further action is required. The data is automatically validated in the Hunter database.





However, if the Headend Radar scans the fiber node but does not receive the node's calibration signal, the following error message below appears on the screen:

Please, increase
Output Level
and/or
check Return Path
cable connection

Fwd SA	Calibrator	CPD Radar
Output Signal	Off	
Output Level	20 dBmV	
Node #	001	
Data Carrier	093.00 MHz	

Calibration Error Message


In this situation, first check the connection. If the connection is secure, increase the output signal level in 5dBmV steps until the system shows calibration confirmation screen. Remember to confirm each signal level change with <ENTER> button.

Calibrating a Device Other Than the Fiber Node

You can connect the Quiver to any device in the network and use Calibrator mode to calibrate the device. Typically, you don't need to calibrate every device, but if there is a major inaccuracy in distance you may want to calibrate to correct this error. Even with significant map inaccuracies, the Quiver will be able to located sources of CPD, the process just might take a little longer. **It is not recommended that any devices other than Fiber Nodes be calibrated.**

Calibrating a non-Fiber Node device in the network begins the same way as if you were calibrating a Fiber Node – first make sure that the Data Carrier, Node Number, and Output Signal are set properly before you switch the Output Signal On.

When you see the following screen, you must choose **No** because you are not at the fiber node.




Admin program.

The message indicating that the calibration signal was properly received at the headend appears as follows for non-Fiber Node devices:

Note: You will need to record the device ID of the calibrated device on a piece of paper. The Quiver automatically stores the Calibration Time Stamp information, which must be compared with the time stamps recorded during calibration, which are stored in the Calibrator database and are accessible by the Client. Both the device ID and time stamp will be needed for the calibration confirmation process.

At this point, the Quiver sends a small simulated CPD signal to the headend radar. As with fiber node calibration, an error screen will appear if the signal is not received by the headend radar, or if the output signal level is too low. Refer to the node calibration section above for more information about the possible error screens.

After the Quiver receives a calibration signal from the headend radar, the next step is to update this calibration information into the device database at the headend server. This is achieved through the calibration confirmation process using the Xcor





Calibrator time stamps can be downloaded over the USB using the Q-Browser program.

The saved Calibrator time stamp for calibrating the fiber node will look like the screen below on the left. And the saved time stamp for a non-fiber node device will look like the screen below on the right.

Calibrator mode

Forward path input

Return path input

CALIBRATION COMPLETE!

Updated fiber node data is automatically written to database

1. Output level	20 dBmV
2. Data carrier	78.00 MHz
3. Node ID	23
4. Start	

Calibrator mode

Forward path input

Return path input

CALIBRATION SIGNAL RECORDED!

ATTENTION!
Calibration needs to be confirmed at headend to update device database!

1. Output level	20 dBmV
2. Data carrier	78.00 MHz
3. Node ID	23
4. Start	

Calibrator time stamps can be cleared using the Q-Browser program and USB connection.


Leakage Detector

The Quiver is equipped with the wide band analog leakage detector. The leakage detection is possible at any analog CW or TV VC signal.

The most easy and effective way for finding the leakage sources is to use frequency range around 650 –750MHz. The antenna can be a simple piece of the coax cable with exposed required length of the center conductor, or a loop dipole can be purchased from Arcom.

To activate the leakage detector, attach the antenna to the left hand side input and select menu item five by highlighting it with the vertical cursor keys or push a number on the numerical keypad.


Then press <Enter> and the following screen will appear:



After checking the connections press <Enter> again. The detector will start working.

The next step is to select required channel frequency that will be used for detection. First select value input method between channel or direct frequency input. This is realized with the <Freq.> soft key. That key toggles between the <Freq.> and


<Chan.>. Then press 1 on the numerical keypad. This action will open the frequency submenu.



In the appearing channel list select the working channel and press <Enter> to confirm the new value.

When the direct frequency input mode is used the submenu will open a field for where the required frequency can be input using the numerical keypad:

After entering the frequency, press <OK> soft button to confirm the new values. If a mistake in the Input is made, use <Clear all> soft key to clear the wrong value and retype the correct value.






When changing frequencies, remember that the antenna length needs to be matching the $\frac{1}{4}$ wave length but doesn't need to be matched precisely when the user needs temporarily to verify signal presence at roughly the desired frequency.

The leak is detected as the analog carrier frequency with associated VBI pulses harmonics that define the analog channel. The entered frequency doesn't need to be exact and depends on the accuracy of the actual modulator at the headend. The frequency span that is used for scanning for the signal is adjustable via the General setting.

Max Hold leak level

This function helps in resolving the final location of the leak. The user can see on the screen what was the max level of the detected signal and return to the antenna position to judge about the source location.

Turn on the Max Hold by pressing the <Max Hold> soft key:



Once the leaking signal reaches the detection threshold that is reflected on the screen by the dotted red horizontal line and the VBI pulses are identified (only for analog TV carriers) the sound will sound (if enabled in the Settings/General settings).



The green caption “Leakage detected – VBI confirmed” will display once the leak is fully identified. The leak level is shown on the spectrum screen and the vertical blue indicator bar.


The marker is automatically set atop of the carrier peak and the level value is displayed in the upper right corner of the screen.

Saving and recalling the leakage trace


To save a leakage trace, use the <Save> soft key. Next, press the <Yes> soft key to confirm selection and the screenshot will be saved into the memory. The traces are available for downloading using the USB port and the Q-Browser software.

RTN Simple Sweep Generator

RTN Sweep (SSG – Simple Sweep Generator) is used to generate 64-point Return Path sweep signals from 5–90 MHz in any desired configuration and level. A software application running the Arcom CPD/Sweep Core is integrated within any PNM platform, and then using standard MIBs that are part of the RPHY specification the core requests FFT return data from the CCAP Core for the desired Remote PHY Node. Upon request from the user with a Smart Phone connecting to the Arcom Core, FFT data from the node is captured, processed by the core, and forwarded to the technician’s smart phone where sweep result is viewed instantaneously. The Quiver-XT also features a receiver that allows the technician to see local swept responses.



The Quiver -XT SSG feature allows the operator to select two types of sweep profiles: Fixed and manual. A manual sweep profile gives the technician sixteen fully configurable frequency points that can set as required. 64-point Fixed sweep profiles can be installed through the Q-browser program revision 5.0.0.11 and above and selected by the user as required.



Manual sweep profile


Manual sweep profile offers an on-site configurable sweep pattern that can be changed at any time. Output level, sweep time and markers are also configurable.

TX Level: Select this option to change the output from +10 to +35 dBmV

Sweep freqs: Select this menu option to adjust 16 frequency points between 5 and 90 MHz.

Sweep time: Allows you to adjust the sweep time from 5mS to 10 mS.

Markers: allows the technician to use two 1 or 2 markers. Markers can be set to Maximum peak, manual adjustment (<>), or off.



Fixed sweep profile


Fixed sweep profile allows for multiple sweep profiles to be pre-stored in the Quiver-XT. A stored profile can be selected from menu option 2. The illustration on the right shows that profile #1, out of two profiles present (#1 (2)) has been selected. Each profile consists of 64 frequency points between 5MHz and 90 MHz.

TX Level: Select this option to change the output from +10 to +35 dBmV

Sweep freqs: Select this menu option to adjust 16 frequency points between 5 and 90 MHz.

Sweep time: Allows you to adjust the sweep time from 5mS to 10 mS.

Markers: allows the technician to use two 1 or 2 markers. Markers can be set to Maximum peak, manual adjustment (<>), or off.




Creating a fixed sweep profile.

A fixed sweep profile is simply a formatted text file transferred into the Quiver using the Q-Browser program.

The file format is as follows:

Line 1, File Title Lines 2 – 65, Point#, :, space , frequency point (MHz) including one decimal (100 kHz).

Profile filenames must be in the format **Profile#.txt**. Where # is a sequential file number. Duplicate numbers will be overwritten without notification.



The screenshot shows a Notepad window titled 'profile2.txt'. The text inside is as follows:


```
#All frequencies in MHz
1: 5.0
2: 5.6
3: 6.2
4: 6.8
5: 7.4
...
60: 40.4
61: 41.0
62: 41.6
63: 42.2
64: 42.8
```

A large blue arrow points from the first few lines down to the last few lines, indicating the sequence of frequency points. The status bar at the bottom right shows 'Ln 1, Co 1'.

Transferring a fixed sweep profile using Q-browser.

Transferring a fixed sweep profile is easy using Q-browser rev 5.0.0.11 and above. Profiles can be overwritten but cannot be deleted. The instructions to follow explain how to transfer a profile into the Quiver XT:

1. Turn the Quiver-XT power on and wait for the main menu to appear. Then connect the Quiver XT by USB to your PC.
2. Launch the Q-browser program and click "Update profile". Click "Ok" when asked to confirm. Navigate to the folder that contains the profile(s), click OK, and then OK to confirm the folder being transferred. The Progress bar will quickly display the transfer and clear.



3. Once the progress bar is clear the transfer is complete. Close Q-browser and disconnect the USB cable from the Quiver.

Note: *Quiver buttons are disabled if Q-browser is running. Disconnecting the USBV cable without closing Q-browser first will disable key function until the power is cycled.*

Quiver Navigator App


The Quiver Navigator App is a useful tool when paired with the Quiver-XT. Using a tablet or smartphone the user will be able to see real time and actual levels marked on a map of the CATV infrastructure.

The Quiver Navigator App can be found on i-Tunes, or Google Play. System maps will need to be configured and placed on the Arcom FTP server prior to use. Discuss placing maps on the Arcom FTP server with your Arcom Digital representative.




Loading maps into your Quiver Navigator App

Download and install your Quiver Navigator App from i-Tunes or Google Play. Once installed, click on the Quiver Navigator icon to launch the application.



After launch the app will leave you with a global view. Click the Navigation Arrow to show your global position.




Next click “MAPS” in the upper right corner of the app to open the map download and installation screen.



Enter your FTP server credentials and click connect. Now use the box below the CONNECT button to navigate to the desired hub maps and click the DOWNLOAD button.


Your Arcom Digital representative can help with your login credentials and the location of your maps.





Once the maps have been downloaded click “Back” to return to the map view.

Now click on the device your Quiver is connected to. A Quiver icon will appear:



QR Codes

Electronic maps and the Quiver Navigator application make it easy to locate faults detected with the use of the Passive CPD, and NTC TDR modes. The Quiver Navigator application provides pin-point locations of devices on a map based on time based measurements. Using logistical troubleshooting techniques, the Quiver can easily be used to locate dominant faults. However, in some cases where multiple passive devices, and even multiple faults exist, fault location can get complicated.

In the case of the NTC TDR, multiple peaks of reflected signals from multiple passive devices can make it difficult to select an actual fault between the user and the next amp. The NTC-TDR will always show the correct Return Loss for the first passive device. But to accurately determine the return loss of devices beyond the first passive, the level of all the peaks beyond the first passive should be recalculated based on the losses in all devices from the TDR to the distant point of reflection.

For example, if the reflected signal of 23 dB comes from a device installed after two splitters (with round trip losses of 7 dB in each) then the actual return loss of that device after recalculation will be $23\text{dB} - (2 \times 7\text{dB}) = 9\text{ dB}$.




In other words, to correctly interpret the actual return loss of the distant device, the NTC TDR response must provide:

1. The identification of each peak with possible devices on a map by using time delay, and;
2. Recalculation of each device RL based on level of peak and the roundtrip losses by devices in the path of the probing signal.


Only after that it will be possible for the user in the field to select a distant peak with bad return loss, which is not an easy task. To solve this problem, a QR code feature is built into the Quiver XT NTC TDR and CPD radar modes. The QR code is read by the mobile device running the Quiver Navigator application, which uses the information embedded in the QR code to recalculate and place delay and level information on a map for the user.

The QR Code function can be activated by pressing “0” on the Passive CPD and NTC TDR screens.





The mobile Quiver Navigator App has been updated to utilize a QR code that contains the details of CPD or Return Loss faults. The Quiver XT includes Passive test CPD and NTC TDR responses you can use to test this feature. To access the test feature use the soft keys and buttons to navigate to “SETTING” and then “4.QR code test”.

Now you are presented with two test options. “NTC TDR” will be illustrated in this example:



To use the QR code, launch the Quiver Navigator App, set the map to your location, and click the device on the map that you are connected to. A Quiver icon will appear at the device indicating your simulated connection. *If you receive a message stating more than one devices were selected then you can either select the desired device from the pulldown list, or zoom in closer to your actual map location and try on the device:* Activate the QR reader function by clicking the “QR” button in upper left corner of the application screen, then place the QR code within the focal grid. You will feel a vibration and the screen will return to the map screen with additional delay details and flags after the QR code has been read.








Clicking the TDR button at the upper left corner will immediately reveal the table of corrected device Return Loss values:



#	Time delay, μ s	RX Level, dB	Device ID	RL, dB
1	0.817	21.1	cable	19.1
2	1.32	25.6	cable	23.6
3	1.841	18.9	cable	16.9
4	2.212	22.7	cable	14.7

tolerance: 25 ns CLOSE TABLE

To select the performance of specific device flags, pull down the delay list at the top center of the screen, select the device or delay you're interested in reviewing and press SEARCH. Now only the device you selected will be displayed.



Click the TDR button and a table appears showing the locations with the worst Return Loss measurements:

Time delay, μs	RX Level, dB	Device ID	RL, dB
0.817	21.1	TM0017	3.10
1.32	25.6	TP0019	15.6
1.841	18.9	SP0005	10.8
2.212	22.7	cable	12.7

tolerance: 125 ns

CLOSE TABLE



Colored coded flag shows recalculated Return Loss


The markers on the app map now display the peak quiver response, the recalculated Return Loss Value, the Return Loss Quality indicated by color, and the type of fault: Device or cable.

Green = Good Return Loss > 17 dB
Yellow = Moderate Return Loss 17 dB < RL > 10 dB
Red = Poor Return Loss < 10 dB






The application also allows the user to select and place specific TDR response peak numbers for a closer, more detailed look.



Changing the Quiver-XT Battery Pack ⚠

The following steps will guide through changing the Quiver Battery Pack once received from Arcom.


1. Remove the Quiver from the protective rubber boot and remove the six Philips screws from the back
2. Remove the two Philips screws from the bracket securing the battery pack.
3. Unplug and remove the old battery pack.
4. Reinstall the new battery pack, battery bracket, and back cover.



Changing the Q-AMP Battery ⚠

The following steps will guide through changing the Q-AMP Battery. Any 9V Alkaline battery can be used.

1. Remove the two Philips head screws from the connector end of the Q-AMP and slide the circuit board out of the chassis.
2. Remove the old battery and reinstall a new one.



3. Reinsert the Circuit Board into the first slot up from the bottom.





Quiver-XT-UB Specifications

Physical

Dimensions = 2.020in X 9.423in X 5.250in (5.136cm x 23.93cm x 13.33cm)

Weight = 2.25 Lb. (1.0 kg)

Environmental

Operating Temperature -15°C to +60C

Operating Humidity 0 to 95 RH

Interfaces

DC INPUT Power Jack 2.5mm

USB mini Type B 5pins

RF "FWD" port "F"-Type Male

RF "Return" port "F"-Type Male

Operating Specifications

NOTE: ALL SPECIFICATION MIGHT CHANGE

Electrical

Current draw: 1.15A

DC INPUT

Charger Voltage = 12VDC+/- 20%, 3.3A Max

Battery = 3.7 VDC, 10.4AH

Charge time: 3 hrs.

Run time: 4 hrs.

Spectrum Analyzer

FWD Port: 57MHz – 1GHz

ResBW: 6 MHz (SLM mode); 30 kHz (spectrum mode)

Input levels: Max: 30dBmV, Min: -50dBmV

RTN Port: 2MHz – 100MHz

ResBW: 100 kHz

Input levels: Max: +20dBmV, Min: -65dBmV



TDR Mode

Return Port TX chirp probe signal: 5MHz – 45MHz

RF Output levels: –10dBmV to +10 dBmV (± 3.5 dBmV)

Max cable length: 1865ft

Cable distance accuracy: 2 feet

Coaxial cable Settings: RG11, RG6, 440, 500, 540, 625, 650, 750, 875, 1000, 1125

CPD Passive radar mode

CPD echo signal bandwidth: 8–16MHz standard resolution, 6 – 42/100 MHz – high resolution (zoom)

FWD input signal level: –10...+25dBmV

CPD Active radar mode

Forward Port Output: TX chirp probe signal: 150 – 250 MHz

RX CPD echo signal bandwidth: 5 – 100 MHz

RF output level: +30 dBmV to +50 dBmV (± 3.5 dBmV)

Bandwidth of FFT spectrum analyzer: ± 20 kHz

Leakage Detector

Tuner frequency step: 1 kHz

ResBW: 20 Hz

Sensitivity: –150dBm

RTN Simple Sweep Generator

Sweep TX Output: +10 dBmV to +35 dBmV ± 1.5 dB, 1 dB steps

Fixed Sweep: Up to 64 frequency steps from 5 MHz to 90 MHz in 100 kHz increments. Default Profile #0, which cannot be deleted is 5 MHz to 90 MHz in 1.5 MHz steps.

Manual Sweep: 16 frequency steps from 5 MHz to 90 MHz / 100 kHz increments

Sweep Time: 5 ms. to 10 ms.

Q-AMP 5/40 and Q-AMP-5/70 MHz Specifications

Physical

Dimensions = 2.750in X 4.125in X 1.125in (6.985cm x 10.478cm x 2.858cm)

Weight = 0.50 lb. (0.226 kg)

Environmental



Operating Temperature -15°C to $+60^{\circ}\text{C}$

Operating Humidity 0 to 95 RH

Interfaces

Momentary Push Button Switch

RF IN port, 75 Ohm "F"-Type Male

RF OUT port, 75 Ohm "F"-Type Male

Operating Specifications

Voltage = 9 Vdc (9V, internal, replaceable, non-rechargeable, alkaline type battery)

Current draw = 0.013 mA

RF Gain, 20 dB / 30 dB Selectable

Frequency Range:

Q-AMP-5/40 = 5 MHz to 40 MHz.

Q-AMP-5/70 = 5 MHz to 70 MHz.

Maximum RF Input = $+20$ dBmV